

SIZE SPECIFICATION:

100" W x 100" H

THE INSTRUCTION SHEET IS APPLICABLE FOR 10 FT. MOUNTING HEIGHT.



FRONT VIEW



SIDE VIEW



REAR VIEW

PARTS	CODE	QTY
-------	------	-----

	1001	2
	1002	2
	1003	2
	1004	4
	1005	2
	1006	2

FRAME ASSEMBLY

STEP 1: CONNECTION

PARTS REQUIRED: 2 1001, 1 1002

- 1. Connect 1001 to 1002 as shown.

STEP 2

PARTS REQUIRED: 2 1001, 1 1003

- 1. Use 1001 to connect 1002 to 1003.
- 2. Connect 1001 to 1003 as shown.
- 3. Connect 1001 to 1003 as shown.

STEP 3

PARTS REQUIRED: 2 1003, 1 1004

- 1. Use 1003 to connect 1003 to 1004.
- 2. Connect 1003 to 1004 as shown.
- 3. Connect 1003 to 1004 as shown.

STEP 4

PARTS REQUIRED: 2 1005, 1 1006

- 1. Connect 1005 to 1006 as shown.
- 2. Connect 1005 to 1006 as shown to the other side to complete the frame.



FABRIC INSTALLATION

1. Fold 1007 and 1008 to 1002 + 1004.
2. Use 1007 and 1008 to connect 1002 to 1004.
3. Connect 1007 and 1008 to 1002.
4. Fold 1009 and 1010 to 1003.
5. Connect 1009 and 1010 to 1003 as shown.
6. Fold 1011 and 1012 to 1005 and 1006.
7. Connect 1011 and 1012 to 1005 and 1006.



1. Minimum 100mm overlap
2. Fabric
3. Minimum 100mm overlap
4. Minimum 100mm overlap
5. Minimum 100mm overlap
6. Minimum 100mm overlap

NOTE: THE FABRIC SHOULD BE MADE APPROXIMATELY 1 FT. ABOVE THE FLOOR.