

DESCRIPTION:

80 x 80 cm



FRONT VIEW



SIDE VIEW



ISOMETRIC VIEW

PART	CODE	QTY
------	------	-----

	01	4
	02	4
	03	2
	04	4
	05	2
	06	2
	07	2

FRAME ASSEMBLY

STEP 1: FRONT RAILS

PARTS REQUIRED: 01, 02, 03, 04, 05, 06

- 1. Insert the two 01 connectors in the 02 and 03 rails.
- 2. Insert the 04 connectors in the 02 and 03 rails.
- 3. Connect the 05 and 06 rails to the 02 and 03 rails.

STEP 2

PARTS REQUIRED: 04, 05, 06

- 1. Place the 04 connectors in the 05 and 06 rails.
- 2. Insert the 05 connectors in the 04 rails.
- 3. Connect the 06 rails to the 05 rails.
- 4. Connect the 06 rails to the 04 rails.

STEP 3

PARTS REQUIRED: 04, 05, 06, 07, 08, 09, 10

- 1. Place the 07 connectors in the 04 rails.
- 2. Connect the 08 rails to the 04 rails.
- 3. Connect the 09 rails to the 04 rails.
- 4. Connect the 10 rails to the 04 rails.
- 5. Connect the 08 rails to the 09 rails.
- 6. Connect the 09 rails to the 10 rails.
- 7. Connect the 10 rails to the 08 rails.
- 8. Connect the 08 rails to the 09 rails.
- 9. Connect the 09 rails to the 10 rails.
- 10. Connect the 10 rails to the 08 rails.



FABRIC INSTALLATION

- 1. Attach the fabric to the 01 connector.
- 2. Attach the fabric to the 02 connector.
- 3. Attach the fabric to the 03 connector.
- 4. Attach the fabric to the 04 connector.
- 5. Attach the fabric to the 05 connector.
- 6. Attach the fabric to the 06 connector.
- 7. Attach the fabric to the 07 connector.
- 8. Attach the fabric to the 08 connector.
- 9. Attach the fabric to the 09 connector.
- 10. Attach the fabric to the 10 connector.



Minimum recommended fabric size: 100 x 100 cm. Fabric must be 100% polyester or 100% polypropylene.

www.milan.com