

Part	Qty
	4
	4
	4
	4
	4
	4

FRAME ASSEMBLY

- STEP 1**
 1. Connect the two corner brackets to a side frame.
- STEP 2**
 2. **NOTE:** Use the corner connector to the back of the corner bracket.
- STEP 3**
 3. **NOTE:** Use the side plate and the top and bottom frame to connect the corner with an other side.
- STEP 4**
 4. **NOTE:** All parts and holes are pre-drilled for the frame. The side connector will take only one other mounting in a connection.



NOTE:
 THE MOUNTING BRACKET MUST BE ATTACHED TO THE BACK OF THE FRAME. THE MOUNTING BRACKET IS AVAILABLE IN BLACK AND SILVER.

WALL MOUNTING

- 1. Use the wall bracket using the pre-drilled holes on the back.



NOTE: WALL MOUNTING IS AVAILABLE IN BLACK AND SILVER.

FABRIC INSTALLATION



STEP 1: Lay the fabric on the back of the frame, ensuring it is centered and covers the entire area.



STEP 2: Smooth the fabric out, ensuring it is flat and free of wrinkles.



STEP 3: Secure the fabric to the back of the frame using the provided fasteners.



STEP 4: Ensure the fabric is properly aligned and secured.



STEP 5: Final check of the fabric installation.



© 2015 Orion Watch Co. All rights reserved. The Orion logo is a registered trademark of Orion Watch Co. Orion is a registered trademark of Orion Watch Co. Orion is a registered trademark of Orion Watch Co.

Model: Orion WF75