

SIZE SPECIFICATIONS

MSD 3070 x 6070



PARTS



CAP



TOP PIN



TOP PIN (2)



TOP PIN

For more information, please visit our website at www.quickstand.com. We are happy to assist you with any questions you may have.

©2018 QuickStand Inc.

ASSEMBLY INSTRUCTIONS

- Remove **QuickStand**® panels from the case - (top/bottom/leg, Side Bar and Corner (corner) Cap).
- Align the top of the case for and tighten the screws. Attach the **top/bottom/leg** bar using the pins to see it. **Figure 1**
- Slide the bottom of the **top/bottom/leg** bar into the bottom hole of the **Side Bar**. Rotate side bar to horizontal and into case. **Figure 2**
- Insert the corner cap into the top bar and leg corner. **Figure 3**
- Insert the top of the **top/bottom/leg** bar into the center hole of the **Side Bar** and the top bar. Tighten and attach the **top/bottom/leg** bar into the corner. Attach bottom of corner to center of Side Bar. **Figure 4**
- Slide the **top/bottom/leg** bar up onto the corner to fit. Tighten and place the top portion of the case. **Figure 5**

